


icountPDZ2



icountPDZ2 User Manual



B.84.833_IPDZ2M_GB_Ver A

© 2010, Parker Hannifin Corporation

www.parkerhfde.com

Overview

Parker Hannifin's IPD Z2 is an on-line laser particle detector. This mineral based hydraulic fluid contamination detector is designed for use in ATEX category 3 areas and is housed in a stainless steel IP69K approved enclosure.

The unit has two size 06L EO 24° cone-end hydraulic connections that allow the fluid to be transferred through the unit for analysis. The electrical supply and communication is made via two M12 Ultra Lock IP69K approved connectors.

Conditions for safe use

To ensure compliance with the certification, users are NOT permitted to open the unit under any circumstances. Doing so will invalidate the unit's calibration and it would NOT be suitable for Hazardous area use.

Contents

Overview	2
Conditions for safe use.....	2
Laser Information.....	4
Declaration of Conformity and Certificate of Manufacture.....	4
Product identification label	5
Introduction	6
Principles of operation	6
Benefits.....	7
Technical specification	8
Software default settings	9
Product features.....	10
Dimensions for installation	10
Connections	11
Hydraulic connection.....	11
Flow control.....	12
System 20 sensor connection	13
Electrical connections	14
Variable current output settings	19
Variable voltage output settings.....	20
CAN-bus output option.....	20
Moisture sensor output settings	20
Digital Display Unit connection	21
RS232 connection	23
Software	24
icountPD Setup Utility software	24
Microsoft Windows® HyperTerminal connection	27
Communication protocol	29
Reference	34
Optional wiring configuration.....	34
Optional Limit Relay hysteresis	34
Interpreting data.....	36
ISO/NAS/SAE comparison chart	40
Component cleanliness guidelines	41
Viscosity charts.....	42
ISO contamination charts.....	43
Ordering Information.....	46

Laser Information

This product contains an invisible infrared 5mW laser.

Any dismantling of the product may result in dangerous exposure to laser radiation.



DANGER

INVISIBLE LASER RADIATION
WHEN OPEN. AVOID DIRECT
EXPOSURE TO BEAM.

CAUTION: Users are not required to access the laser radiation source and should never do so.

Declaration of Conformity and Certificate of Manufacture

CE conformity

The IPD Z2 is in conformity with the protection requirements of the following European Standards in English:

- Directive 94/9/EC of the European Parliament and the Council, for equipment intended for use in potentially explosive atmospheres (ATEX).
- EN 60079-0:2009, Electrical apparatus for explosive gas atmospheres General requirements.
- EN 60079-15:2005, Electrical apparatus for explosive gas atmospheres – Construction, test and marking of type of protection “n” electrical apparatus.
- EN 61241-1:2004, Electrical apparatus for use in the presence of combustible dust. Protection by enclosures “tD”
- IECEx 60079-0:2006 ed 4.0 (IECEx 60079-0:2007 ed 5.0) – Electrical equipment for explosive gas atmospheres – Part 0: General requirements
- IECEx 60079-15 :2005 ed 3.0 – Electrical apparatus for explosive gas atmospheres – Part 15: Construction, test and marking of type of protection “n” electrical apparatus
- IECEx 61241-1:2004 ed 1: IECEx Test Report for IEC 61241-1 (2004) ed 1.0 – Electrical apparatus for use in the presence of combustible dust – Part 1: Protection by enclosures “tD”

The Product(s) described above are in conformity with the essential requirements of the following directives:

89/336/EEC amended by 92/31/EEC, 93/68/EEC and repealed by 2004/108/EEC


Harmonised standards:

EN61000-6-3:2007 Electromagnetic compatibility – Part 6-3: Generic standards – Emission standard for residential, commercial and light-industrial environments.

EN61000-6-2:2005 Electromagnetic compatibility (EMC) – Part 6-2: Generic standards – Immunity for industrial environments

Product identification label

The identification label attached to the enclosure (an example is given below) is explained in the table that follows:



Item	Field	Values
1	Part Number	icountPDZ2
2	D.O.M.	Date of manufacture
3	Serial Number	The serial number consists of eight digits, for example: GD6NN001 (‘GD’ is the month and year; ‘6NN’ is the product group; the last three digits are entered sequentially through a month, reverting to ‘001’ at the beginning of each month)
4	Manufactured	Country of manufacture (United Kingdom)
5	Name and address of manufacturer	Parker Hannifin (UK) Ltd, Filter Division Europe, Condition Monitoring Centre, Brunel Way, Thetford, Norfolk, IP24 1HP, UK
6	ATEX certification number	Ex = European mark II = Non-mining 3 = Equipment category (Zone 2/22) GD = Type of explosive atmosphere (G = Gas, D = Dust)
7	ATEX/IECEx category 3 certificate coding (Gas)	Ex = Explosion protected nA = Type ‘n’ (non-sparking) IIC = Gas group T4 = Temperature class (4 = maximum surface temperature of 135°C) Gc = Equipment protection level (G = Gas, c = Zone 2)
8	ATEX/IECEx category 3 certificate coding (Dust)	Ex = Explosion protected tc = Protection by enclosure IIIC = Equipment grouping typical dust material Dc = Equipment protection level (D = Dust, c = Zone 2)
9	CE Conformity marking and number of notified body responsible for audit production	CE 0518
10	Certificate Numbers	SIRA 09ATEX4340X IECEx SIR 09.0137X
11	Ambient operating temperature	Between -30°C and +60°C

Introduction

Parker Hannifin's icountPDZ2 represents the most up-to-date technology in solid particle contamination analysis. The icountPDZ2 is a compact, permanently-mounted laser-based particle detector module that provides a cost-effective solution to fluid management and contamination control.

Principles of operation

The icountPDZ2 measures particle contamination continuously and updates the output options and limit relay every second.

Unlike the Parker CM20, LCM20 or MCM20, the unit does not perform a 'one-off' test. This means that even if the Measurement Period is set to 60 seconds, the output and limit relay all report the presence of dirt in the oil in just a few seconds – it does not wait until the end of the Measurement Period before reporting the result.


The icountPDZ2 has just one setting to control the accuracy, stability and sensitivity of the measurements and that is the 'Measurement Period'. This can be set from 5 seconds to 180 seconds. The longer the Measurement Period, the more contaminant is measured, averaging out any spikes seen on a smaller sample. The shorter the Measurement Period, the more sensitive the icountPDZ2 is to small slugs of contaminant, but it can also reduce the performance on clean systems. Thus, the user can select how sensitive the icountPDZ2 is to spikes of contaminant, and how quickly it responds to contamination levels above the set point ('limits').

With a Measurement Period of 100 seconds, the results will be for the last 100ml of oil that has flowed through the icountPDZ2, updated on a second-by-second basis, giving an effectively continuous readout of the level of contamination.

Calibration recommendations

NOTE: Any servicing or repair work must be carried out by a Parker ATEX approved service centre. Contact your local Parker Hannifin Sales Company for recalibration details. The recommended period between recalibration is 12 months.

Please refer to the Parker Hannifin Quality and Servicing booklet (FDCB272UK), supplied on CD.



Benefits

- Independent monitoring of system contamination trends
- Calibration by recognised online principles confirmed by relevant International Organization for Standardization (ISO) procedures
- Indicators for Low, Medium and High contamination levels
- A low cost solution to prolonging fluid life and reducing machine downtime
- Self-diagnostic software
- Mineral fluid-compatible construction
- Fully PC/PLC integration technology such as: RS232, 0–3V/0–5V, 4–20mA and CAN-bus (SAE J1939) – see the ‘Product Configurator’, page 46, for communication options
- Percentage saturation reporting through an integrated moisture sensor – see the ‘Product Configurator’ on page 46, for the moisture sensor option.

Technical specification


Feature	Specification
Product start-up time	5 seconds minimum
Measurement period	5–180 seconds
Reporting interval	0–3600 seconds via RS232 communication
Principle of operation	Laser Diode optical detection of actual particulates
International codes	ISO 7 – 22, NAS 0 – 12
Calibration	By recognised online methods confirmed by the relevant ISO procedures. MTD – Via a certified primary ISO 11171 automatic particle detector using ISO 11943 principles, with particle distribution reporting to ISO 4406:1996 ACFTD – Conforming to ISO 4402 principles with particle distribution reporting to ISO 4406:1996
Recalibration	Contact Parker Hannifin
Working pressure	2–420 bar (30–6000 PSI)
Flow range through icountPDZ2	Note: Flow may be bi-directional 40–140 ml/min (optimum flow 60 ml/min) (0.01 – 0.04 USGPM (optimum flow 0.016 USGPM))
Online flow range via System 20 sensors	Size 0 = 6 to 25 l/min (2–7 USGPM) Size 1 = 24 to 100 l/min (6–26 USGPM) Size 2 = 170 to 380 l/min (45–100 USGPM)
Ambient storage temperature	–40°C to +80°C (–40°F to +176°F)
Environment operating temperature	–30°C to +60°C (–22°F to 140°F)
Fluid operating temperature	+5°C to +80°C (+41°F to 176°F)
Computer compatibility	Parker recommends the use of a 9-way D-type connector. This can be connected to a USB port using a USB-serial adaptor. Note that these connectors/adaptors are NOT supplied with icountPDZ2 units: contact Parker Hannifin for advice.
Moisture sensor calibration	±5% RH (over compensated temperature range of +10°C to +80°C; +50°F to +176°F)
Operating humidity range	5% RH to 100% RH
Moisture sensor stability	±0.2% RH typical at 50% RH in one year
Power requirement	Regulated 9–40Vdc
Current rating	Typically 120mA
Certification	IP69K rating EC Declaration of Conformity (see page 4).
Analogue output options (specified when ordering)	
Variable current	4–20mA
Variable voltage	0–5Vdc, 0–3Vdc (user selectable)
CAN-bus	to SAE J1939 (e.g. <i>Parker IQAN</i>)
Moisture sensor	Linear scale within the range 5% RH to 100% RH

Software default settings

Standard defaults	
Comms echo	OFF
Verbose errors	OFF
STI Sensors used	OFF
Reporting standards	ISO
Particle limits	19 / 18 / 15
Measurement period	60 seconds
Reporting interval	30 seconds
Power-on mode	AUTO
Auto start delay	5 seconds
Date format	dd/mm/yy


Default if options fitted	
Relay hysteresis	ON
Relay operation for particle limits	ON
Relay operation for moisture sensor limits	ON
0–5V/0–3V output voltage range	0–5V
Moisture sensor limit	70%

Product features



Dimensions for installation

Dimensions are given in mm (inches)



Connections

Hydraulic connection


Our recommendation is to position the icountPDZ2 as close to the system output as possible whilst controlling the flow to the optimum 60ml/min. This then provides the highest pressure conditions, plus the oil in this position is indicative of the reservoir's oil condition.

The IPDZ2 is supplied with two size 06L EO 24° cone-end hydraulic connections.


For hydraulic connection, ensure that the hydraulic/pipe connection fitting is compatible with the size 06L EO 24° cone bulkhead fitting.

Assembling the EO nut fitting

- Step 1** Press the tube-end firmly into the assembly core.
- Turn back the nut for easy tube insertion and fit the nut hand tight, then tighten the fitting until you feel a sharp increase in resistance.




- 2** Ensure the bulkhead fitting is held with a 17mm spanner and tighten (approximately 1 to 1½ turns).



- 3** Now remove the pipe and nut to check assembly.


The gap between sealing ring and retaining ring must be closed. A little relaxation (approximately 0.2mm) is allowed.

If the gap is not closed: Check all components, including the tube.



- 4 Assemble the fitting until wrench-tight (without spanner extension).

Tighten the fitting firmly by a minimum 1/6 (max 1/4) turn (i.e. 1 to 1½ flats)



Flow control

A pressure compensated, flow control device (Parker Hannifin part number S840074) has been developed to give the icountPDZ2 user greater flexibility. The flow control device enables testing where flow ranges are outside the icountPDZ2 specifications (i.e. 40–140 ml/min), or where pipe diameters do not allow the icountPDZ2 to be installed.

REQUIRED DIFFERENTIAL PRESSURE RANGE 5–315 BAR

The flow control device fits onto the downstream (outlet) side of the icountPDZ2, connecting through a manifold block via a self-sealing quick connection test point.

The differential pressure valve automatically compensates for pressure and viscosity changes, whilst maintaining its flow setting even as the workload changes.

The table below is used to select the appropriate valve position:

Valve position	cSt range
3	20–100
3.8	90–200
4.2	190–320
5	310–500



System 20 sensor connection

Online flow range via System 20 inline sensors:


Size 0	6 to 25 l/min (optimum flow = 15 l/min)
Size 1	24 to 100 l/min (optimum flow = 70 l/min)
Size 2	170 to 380 l/min (optimum flow = 250 l/min)

The required differential pressure across inline sensors is 0.4 bar (minimum)


Refer to the 'Sensor part numbers' section on page 46 before ordering System 20 sensors.

See 'Inline Sensor Monitors' (Parker Hannifin Brochure CM013GB1) for more information on System 20 sensors.


Size 0 Sensor



Size 1 Sensor



Size 2 Sensor




(All dimensions are in millimetres)

IMPORTANT NOTE: P1 and P2 of the System 20 sensors MUST be connected to the icountPDZ2 test points. Ensure that the icountPDZ2 command 'SSU' is set to 'Yes' when connecting to icountPDZ2 – refer to 'Communication protocol' section of this manual for a list of user commands.

Contact Parker Hannifin if you require further advice in connecting icountPDZ2 to your system.


Electrical connections

The M12 8-pin Ultra Lock connection system uses innovative push-to-lock technology to make a quick but secure connection. The unique O-ring radial seal is operator-independent, so there is no chance of over-tightening or under-tightening.



IMPORTANT NOTE: The IP69K Ingress Protection is only valid when using the M12 Ultra Lock mating connector cable (supplied).

CONNECTING/DISCONNECTING




Ensure that the locating pin and slot are correctly aligned (to avoid damaging the pins) and push home firmly to connect. To disconnect, pull the Ultra Lock's metal collar back to release the cable lock and pull the cable boot out squarely.

WIRING DIAGRAMS

Wiring diagrams are provided (on pages 16–17), showing how a digital multimeter may be connected to the Communication cable and the Supply and Limit Relay cable, for both voltage and current options. The connections for an optional moisture sensor (if fitted) are also shown.

A diagram for connecting the icountPDZ2 to an external CAN-bus network is given on page 18.

Communication cable connector



Pin configuration diagram


M12, 8-pin Ultra Lock IP96K female connector, end view

Pin number (Wire colour recommended)	No options fitted	4–20mA option fitted	0–5V/0–3V option fitted	CAN-bus option fitted
1 (White)	NOT USED	Channel C, ISO 14µm(c)	Channel C, ISO 14µm(c)	NOT USED
2 (Brown)	RS232 Ground (* Pin 5)	RS232 Ground (* Pin 5)	RS232 Ground (* Pin 5)	RS232 Ground (* Pin 5)
3 (Green)	NOT USED	Channel A, ISO 4µm(c)	Channel A, ISO 4µm(c)	CAN+ (Hi)
4 (Yellow)	NOT USED	Channel B, ISO 6µm(c) or NAS (if selected)	Channel B, ISO 6µm(c) or NAS (if selected)	CAN– (Lo)
5 (Grey)	RS232 Receive (* Pin 3)	RS232 Receive (* Pin 3)	RS232 Receive (* Pin 3)	RS232 Receive (* Pin 3)
6 (Pink)	RS232 Transmit (* Pin 2)	RS232 Transmit (* Pin 2)	RS232 Transmit (* Pin 2)	RS232 Transmit (* Pin 2)
7 (Blue)	NOT USED	Moisture sensor channel (if fitted)	Moisture sensor channel (if fitted)	CAN Ground
8 (Red)	NOT USED	NOT USED	NOT USED	NOT USED

** Parker Hannifin recommends the use of a 9-way D-type socket with RS232, using the pin configurations given in the above table.*

NOTE: If the moisture sensor is fitted without the 4–20mA or the 0–5V/0–3V option, then the output is via RS232.

Supply and Limit relay cable connector




Pin configuration diagram

M12, 8-pin Ultra Lock IP69K-rated, male connector, end view


Pin number (Wire colour recommended)	No options fitted	4–20mA option fitted	0–5V/0–3V option fitted	CAN-bus option fitted
1 (White)	Relay Normally Closed (if fitted)	Relay Normally Closed (if fitted)	Relay Normally Closed (if fitted)	NOT USED
2 (Brown)	NOT USED	4–20mA Supply 12–20Vdc	0–5 / 0–3V Supply 12–24Vdc	NOT USED
3 (Green)	Relay Common (if fitted)	Relay Common (if fitted)	Relay Common (if fitted)	NOT USED
4 (Yellow)	Relay Normally Open (if fitted)	Relay Normally Open (if fitted)	Relay Normally Open (if fitted)	NOT USED
5 (Grey)	NOT USED	NOT USED	NOT USED	NOT USED
6 (Pink)	NOT USED	NOT USED	0–5V / 0–3V Supply 0 Vdc	NOT USED
7 (Blue)	Product supply 0Vdc	Product supply 0Vdc	Product supply 0Vdc	Product supply 0Vdc
8 (Red)	Product supply 9–40Vdc	Product supply 9–40Vdc	Product supply 9–40Vdc	Product supply 9–40Vdc

IMPORTANT NOTE: It is the responsibility of the end user to ensure that the cable's braided screen is terminated to a suitable earth bonding point.


M12, 8-pin connector: 0–5V/0–3V voltage measurement



M12, 8-pin connector: 4–20mA current measurement



CAN-bus (SAE J1939) connections




Variable current output settings

ISO setting

The following table can be used to relate an analogue output (in mA) to an ISO code. For example, an output of 10mA is equal to an ISO code 12.

mA	4.0	4.5	5.0	5.5	6.0	6.5	7.0	7.5	8.0	8.5	9.0	9.5	10.0	10.5	11.0	11.5	12.0
ISO	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16

cont.	mA	12.5	13.0	13.5	14.0	14.5	15.0	15.5	16.0	16.5	17.0	17.5	18.0	18.5	19.0	19.5	20
	ISO	17	18	19	20	21	22	*	*	*	*	*	*	*	Over-range	ERROR	



The actual calculation is as follows:

$$\text{ISO code} = (\text{output in mA} - 4) \times 2$$

e.g. $(11.5\text{mA} - 4) \times 2 = 7.5 \times 2 = \text{ISO } 15$


* = Saturation (i.e. above ISO code 22)

NAS setting

The following table can be used to relate an analogue output (in mA) to a NAS code. For example, an output of 15mA is equal to NAS code 10.

mA	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
NAS	00	0	1	2	3	4	5	6	7	8	9	10	11	12	*	*	ERROR

Note: * = Saturation (above NAS code 12)



The actual calculation is as follows:

$$\text{NAS code} = (\text{output in mA} - 4)$$

e.g. $15\text{mA} - 4 = \text{NAS } 11$

* = Saturation (i.e. above NAS code 12)

Variable voltage output settings

The variable voltage output option is capable of two different voltage ranges: a 0–5Vdc range as standard, and a user-selectable 0–3Vdc range. The 'Full list of commands' section of this manual (page 30–32) gives information on how to change the voltage output range.

The following tables can be used to relate the analogue output to an ISO or NAS code.

For example, in a 0–5Vdc range, ISO code 16 is equal to an output of 3.5Vdc. In a 0–3Vdc range, ISO code 8 is equal to an output of 1.0Vdc.

Table relating ISO codes to Voltage output

ISO	Err	0	1	2	3	4	5	6	7	8	9	10	11
0–5Vdc	<0.2	0.3	0.5	0.7	0.9	1.1	1.3	1.5	1.7	1.9	2.1	2.3	2.5
0–3Vdc	<0.15	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0	1.1	1.2	1.3

cont.	ISO	12	13	14	15	16	17	18	19	20	21	22	Err
	0–5Vdc	2.7	2.9	3.1	3.3	3.5	3.7	3.9	4.1	4.3	4.5	4.7	>4.8
	0–3Vdc	1.4	1.5	1.6	1.7	1.8	1.9	2.0	2.1	2.2	2.3	2.4	>2.45

Table relating NAS codes to Voltage output

NAS	Err	00	0	1	2	3	4	5	6	7	8	9	10	11	12	Err
0–5Vdc	<0.4	0.6	0.9	1.2	1.5	1.8	2.1	2.4	2.7	3.0	3.3	3.6	3.9	4.2	4.5	>4.6
0–3Vdc	<0.2	N.S.	0.3	0.5	0.7	0.9	1.1	1.3	1.5	1.7	1.9	2.1	2.3	2.5	2.7	>2.8

(N.S. = Not Supported)

CAN-bus output option

If you plan to use the icountPDZ2 with a CAN-bus (SAE J1939) network, you can order this output option when specifying the unit. Refer to the 'Product configurator' (page 46) in the Reference section of this manual. The CAN option provides an interface to external CAN-bus networked systems – for example, to the *Parker IQAN*.

Moisture sensor output settings


The Moisture sensor is an option that can be included when specifying the icountPDZ2. Refer to the 'Product configurator' (page 46) in the Reference section of this manual.

The Moisture sensor reports on the saturation levels of the fluid passing through the icountPDZ2 sensing cell. The output is a linear scale, reporting within the range of 5% saturation to 100% saturation.

Table relating Saturation levels in the sensing cell to icountPDZ2 outputs

Saturation	4–20mA	0–3Vdc	0–5Vdc
5%	4.8	0.15	0.25
25%	8	0.75	1.25
50%	12	1.50	2.50
75%	16	2.25	3.75
100%	20	3.00	5.00


Digital Display Unit connection



The above diagram shows how a set of Parker Hannifin DDUs can be used to display Channels A, B and C, plus the Moisture sensor (if fitted).

DIGITAL DISPLAY UNITS AVAILABLE

Part number	Description
DDU1001	Process indicator, 22–55Vdc
DDU1002	Process indicator, 90–264Vdc



The above diagram shows how a single DDU can be used to display Channels A, B and C, plus the Moisture sensor (if fitted), by using a switch to display each channel in turn.

RS232 connection

Communication can be established between icountPDZ2 and a PC using an RS232 serial connection with the **Parker Utility Setup Tool**, the **Parker Terminal** utility, or via Microsoft Windows® **HyperTerminal**.

Please note that **HyperTerminal** is not supplied with Windows Vista™, but the **Parker Utility Setup Tool** and **Parker Terminal** can be used with this operating system. Both Parker programs are supplied on the icountPD CD.

PC connection

The RS232 wires need to be connected to a 9-way D-type connector (not supplied as standard). For the connector pin termination and wire colour, refer to the 'Communication cable connector' section of this manual (page 15).

The device can then be either connected direct to PC serial port (Figure 1) or connected via an RS232-to-USB adaptor cable (Figure 2).

An RS232 to USB convertor can be supplied by Parker Hannifin (part number ACC6NN017).




Figure 1




Figure 2

NOTE: The 9-way D-type connector, RS232-to-USB adaptor cable and installation software are not supplied as standard with the icountPDZ2.

Software

The icountPDZ2 may be configured using the icountPD Setup Utility, supplied on CD.

For more direct control of the device using its communications protocol, you may use the **Parker Terminal** program: both Parker programs are supplied on the icountPDZ2 CD. You may also use Microsoft Windows® **HyperTerminal** program, but note that this program is not currently supplied with the Windows Vista™ operating system.

icountPD Setup Utility software

PC Installation

The icountPD Setup Utility and Parker Terminal software is available on the CD supplied with the icountPDZ2. The software can be run directly from the CD or copied to a PC hard drive.

Using the icountPD Setup Utility

Check that the icountPDZ2 is connected to power and the communication cable is connected to the PC via the RS232 plug.


Place the CD in your PC drive and wait for the selection screen to appear. On starting the software, the icountPD Setup Utility screen appears.


Step 1A:

With the icountPDZ2 connected to power and the RS232 connected to the PC, select the appropriate communication port.

Step 1B:


Note the status of the icountPDZ2.




**Step 2:**

Set the values for 'Detector ID' and 'Date Format'.

The remaining detector information is preset by Parker Hannifin and cannot be changed.

**Step 3:**

Set the values in 'Measurement Configuration', 'Relay Options' and 'Alarm Limits'.

**Step 4:**

Set the Voltage Range (0–5V, 0–3V or J1939) in 'Output Options' according to the options fitted.

iCount Setup Utility

File Options Help

Communications

Port: COM1
Disconnect
☐ Comms Echo
☒ Verbose Errors

Measurement Configuration

STI Sensor Used ☐
Reporting Standard: ISO
Measurement Period: 120 sec
Interval: 0 m, 5 s
Power-On Mode ☒ Auto Start
Auto start delay: 5 sec

Sensor Configuration

Detector ID: OLED 4-20 Eng
Product ID: icount PD
Part Number: ipd12211200
Serial Number: AB6NW016
Firmware: 1.02.01
Date Format: dd/mm/yy
Calibration Date: 12/07/07
Calibration Due Date: 01/12/08
Calibration Dust: MTD

Relay Options

Relay Hysteresis: ☒ On
Relay Operation: ☒ Particle Limits
☒ Moisture Limits
Manually Operate Relay: On Off

Display Options

Orientation: 0°
Brightness Level: 3 - mid

Output Options

Voltage Range: [dropdown]

Alarm Limits

Particle Limits: 14 4µ, 12 6µ, 10 14µ
Moisture Limit: 60 %RH

Results

Class/Codes: 15/13/12
Moisture %RH: 50
Relay State: On
Start Stop

Connected Running

Step 5:

Setup values are verified as valid in 'Results'.

Click 'Start' to start verification and 'Stop' to stop.

Microsoft Windows® HyperTerminal connection

An alternative way of achieving communication with icountPDZ2 is to use the HyperTerminal program supplied with Microsoft Windows (but not always installed on the PC or laptop's hard disk – check the installation disk, or contact your organisation's IT department if the program is not present). **Please note that HyperTerminal is not supplied with Windows Vista™, but the Parker Terminal utility can be used with this operating system.**

The standard communication settings (used in STEP 4) are as follows:

Baud Rate	9600
Data bits	8
Parity	None
Stop bits	1
Flowcontrol	None




Step 1:
Click 'Start'

Step 2:

Select 'HyperTerminal'.

(from All Programs
► Accessories
► Communications
► HyperTerminal)



Step 3:



Click and type the connection name you wish to use to identify this session

**Step 4:**

Select the appropriate USB port.

Step 5:

Enter the communication settings (as in the 'standard communications settings' table, on the previous page).

**Step 6:**

Once the iCountPDZ2 is connected to power, the product identification is displayed.

This confirms that communication to iCountPDZ2 has been established and the unit is now ready for operation.

Communication protocol

The commands used with the icountPDZ2 are either made up of Set, Read or Start/Stop commands.

- Set commands allow the value or values of parameters to be changed
- Read commands allow the value or values of parameters to be read
- Start/Stop commands allow the user to start and stop tests.

Example:

[SDF dd/mm/yy] sets the date format

[RDF] reads the product format date

All commands are sent in ASCII characters, and the protocol accepts both upper and lower case characters. For example, all of the following codes are equivalent:

SDF = Sdf = SdF = sdf = sdf

NOTE: The use of a '=' after a command, for example [SDF = dd/mm/yy], is optional.

Certain commands are for expert use only and can be accessed via a password system. Should an unauthorized person attempt to access these commands the icountPDZ2 returns the error code for 'Invalid Command'.

A list of error codes is given on page 33.

Most-used commands

Common User Read commands		
Command	Description	icountPDZ2 response
RDU	Read calibration dust	Calibration dust displayed (i.e. MTD or ACFTD)
RLT	Read NAS or ISO limits	Limits displayed
RRS	Read reporting standard	ISO or NAS displayed

Common User Set commands		
Command	Description	User response
SLT	Set limits i.e. 'SLT 19 18 15'	SLT ## ## ## (for ISO) SLT ## (for NAS)
SRS	Set reporting standard	SRS iso SRS nas
SRI	Set reporting interval 0 to 3600 seconds 0 = No reporting	SRI #####

NOTE: The reporting interval (SRI) controls how often the icountPDZ2 sends results over the RS232.

User Start/Stop commands		
Command	Description	Response
STR or START	Start testing	'OK' displayed
STP or STOP	Stop testing	'OK' displayed

Full list of commands

User Read Commands		
Command	Description	icountPDZ2 response
RCD	Read the last C alibration D ate	Last calibration date displayed
RCE	Read C ommunication E cho	'ON' or 'OFF' displayed
	<i>Comms Echo ON allows the icountPDZ2 to communicate in two directions (Hyperterminal)</i> <i>Comms Echo OFF allows the icountPDZ2 to communicate in one direction (Setup Utility)</i>	
RDD	Read the next calibration D ue D ate	Next calibration due date displayed
RDF	Read D ate F ormat	Date format displayed (e.g. dd/mm/yy)
RDI	Read D etector I D	Detector ID displayed
RDS	Read D etector S tatus	IPD status displayed (e.g. RUNNING)
RDU	Read the calibration D ust U nit	Calibration dust displayed (i.e. MTD or ACFTD)
REN	Read last E rror N umber	Last error number displayed
RER	Read last E rror text R eport	Last error text displayed
REV	Read the E rror V erbose mode	Error verbose mode displayed
	<i>Error Verbose ON displays the full description of the error code (i.e. Error 40 – expected On or Off)</i> <i>Error Verbose OFF displays just the error code (i.e. Error 40)</i>	
RFN	Read F ault N umber	Fault number displayed
RJE	Read J 1939 Status	'ON' or 'OFF' displayed
RLR	Read the L ast contamination R esult	Last contamination result displayed
RLT	Read contamination L imit T hreshold	Contamination limits displayed
RML	Read M oisture sensor L imit ¹	Moisture limit displayed
RMP	Read M easurement P eriod	Measurement period displayed
RMV	Read the last M oisture sensor V alue ¹	Last moisture result displayed
ROF	Read O ptions F itted	ROF = ABCDEFGHIJ (see list of options below)
RON	Read O ption N ame	List of options A = Alarm relay option B = LED display option C = OLED display option D = Moisture sensor option E = 4–20mA current loop option F = 0–3/0–5V option G = J1939 option H = reserved I = reserved J = reserved
RPD	Read the P ower on hold-off D elay	Power hold-off delay displayed
RPI	Read P roduct I dentifier	icountPDZ2 displayed
RPM	Read the P ower on M ode	'AUTO' or 'MANUAL' displayed
RPN	Read the icountPDZ2 P art N umber	Parker part number displayed
RPT	Read P roduct T ype	IPDH
RPV	Read P rotocol V ersion	Protocol version displayed
RRI	Read R eporting I nterval	Reporting interval displayed
RRS	Read R eporting S tandard	'ISO' or 'NAS' displayed
RSB	Read Software Build number	Software build number displayed
RSH	Read limit relay S witch H ysteresis ²	'ON' or 'OFF' displayed
RSL	Read S tandards L ist	ISO, NAS

RSN	Read S erial N umber	Serial number displayed
RSS	Read limit relay S witch S tate ²	'ON' or 'OFF' displayed
RSU	Read STI S ensor U sed	'YES' or 'NO' displayed
RSV	Read S oftware V ersion displayed	Software version displayed
RVM	Read the V oltage M aximum range ³	Voltage range displayed
RWC	Read W arning limit relay for C ontamination ²	'ON' or 'OFF' displayed
RWM	Read W arning limit relay for M oisture ^{1,2}	'ON' or 'OFF' displayed

¹ Command requires a Moisture Sensor to be fitted to icountPDZ2

² Command requires a Limit Relay to be fitted to icountPDZ2

³ Command requires a 0–5V option to be fitted to icountPDZ2

User Set Commands

Command	Description	icountPDZ2 response
SCE	Set C ommunication E cho	SCE on SCE off
<p><i>Comms Echo ON allows icountPDZ2 to communicate in two directions (Hyperterminal)</i> <i>Comms Echo OFF allows icountPDZ2 to communicate in one direction (Setup Utility)</i></p>		
SDF	Set D ate F ormat	SDF dd/mm/yy SDF mm/dd/yy SDF yy/mm/dd
SDI	Set D etector I D	SDI ##### (14 characters maximum, spaces not allowed)
SEV	Set the E rror V erbose mode	SEV on SEV off
<p><i>Error Verbose ON displays the full description of the error code (i.e. Error 40 – Expected On or Off)</i> <i>Error Verbose OFF displays just the error code (i.e. Error 40)</i></p>		
SJE	Set J 1939 Status	SJE On/Off (can only set On)
SLT	Set contamination L imit T hreshold	SLT ## ## ## (for ISO) SLT ## (for NAS)
SML	Set M oisture sensor L imit ¹	SML ###
SMP	Set M easurement P eriod	SMP ### (### = 5 to 180 seconds)
<p><i>The Measurement period sets the number of seconds the detector uses to determine the contamination levels. So if this is 60 seconds, the unit will use the last 60 seconds of oil to determine the contamination level. (See the 'Component cleanliness guideline' chart in the Reference section of this manual.)</i></p>		
SPD	Set the P ower on hold-off D elay	SPD ### (### = 0 to 900 seconds)
<p><i>The Power-on hold-off delay command allows the user to delay the start of the icountPDZ2 operation.</i></p>		
SPM	Set the P ower on M ode	SPM auto SPM manual
<p><i>With the Power-on Mode set to 'Auto' icountPDZ2 starts testing automatically when the power is connected using the last setup parameters. With the Power-on Mode set to 'Manual' icountPDZ2 becomes idle and requires the user to manually start testing.</i></p>		
SRI	Set R eporting I nterval	SRI mm:ss (0 to 3600 seconds (i.e. 0–1 hour); note that 0 = No reporting)

The Reporting Interval controls how often icountPDZ2 sends results over the RS232

SRS	S et R eporting S tandard	SRS iso SRS nas
SSH	S et limit relay S witch H ysteresis ²	SSH on SSH off
SSS	S et limit relay S witch S tate ²	SSS on SSS off
SSU	S et STI S ensor U sed	SSU yes SSU no
SVM	S et the V oltage M aximum range ³	SVM # (3 = 0–3Vdc output 5 = 0–5Vdc output)
SWC	S et W arning limit relay for C ontamination ^{2, 4}	SWC on SWC off
SWM	S et W arning limit relay for M oisture ^{1, 2, 4}	SWM on SWM off

¹ Command requires a Moisture sensor to be fitted to the icountPDZ2

² Command requires a Limit Relay to be fitted to the icountPDZ2

³ Command requires a 0–5Vdc option to be fitted to the icountPDZ2

⁴ If the Limit Relay has been turned OFF for both Contamination monitoring and Moisture sensing, the Limit Relay will not operate, but the alarm status is not affected.

If the Limit Relay has been turned ON for both Contamination monitoring and Moisture sensing, the Limit Relay will operate when any alarm condition is reached.

Error codes

If a command does not follow the protocol, an explanatory error code is returned.

Depending on the setting of **SEV** (**S**et the **E**rror **V**erbose mode), either the error code, or the error code and message are displayed.

For example, with **SEV OFF** (Error Verbose off) just the error code (e.g. **Error 40**) is returned. With **SEV ON** (i.e. Error Verbose on) both the error code and message (e.g. **Error 40 - Expected On or Off**) are returned.

Messages corresponding to the error codes are given in the following table:

Code	Message
Error 0	No error
Error 1	Unknown command
Error 2	Characters after command ignored
Error 3	Command ignored – unit is busy
Error 5	Unexpected character found
Error 6	Symbol too long
Error 7	Bad command format
Error 8	Unknown value
Error 9	Invalid date format
Error 10	Invalid date
Error 13	Option not fitted
Error 14	String too short
Error 15	String too long
Error 17	No test result
Error 18	Number expected
Error 19	Number too long
Error 20	Number out of range
Error 30	Interval shorter than duration
Error 40	Expected On or Off
Error 41	Expected Disabled or Enabled
Error 43	Expected Auto or Manual
Error 45	Expected Yes or No

Reference


Optional wiring configuration

Supply and Limit Relay cable wiring configuration

The icountPDZ2 can be specified to include a built-in limit switch relay which can be triggered when a preset alarm level is reached. The relay contacts can be used to switch an external device on or off.

These wires within the icountPDZ2 Supply and Limit Relay cable may be identified by their colour: Yellow, White and Green, and are connected according to the diagram below.

Wire colour	Description
Yellow	Normally Open
White	Normally Closed
Green	Common



The contact rating is 5A at 5–24Vdc

IMPORTANT NOTE: It is the responsibility of the end user to ensure that the cable's braided screen is terminated.

Optional Limit Relay hysteresis

Hysteresis is a property of systems (usually physical systems) that do not instantly follow the forces applied to them, but react slowly, or do not return completely to their original state.

To set Relay Limits, refer to the 'Communication Protocol – User Commands' section in this manual.

HYSTERESIS FEATURE ON

The relay will energise when any channel is one code above the set limit and will only de-energize when all channels are one code below the set limit.

HYSTERESIS FEATURE OFF

The relay will energise when any channel is one code above the set limit and will only de-energize when all channels are on the set limit.

EXAMPLE ISO SCENARIO

An icountPDZ2 has been connected to a hydraulic fluid transfer system. With the icountPDZ2 limit relay switched off (Normally Closed), the limits set to ISO 20/18/13 and the relay cable electrically connected to a Parker 10MFP Filtration Trolley. The icountPDZ2 will activate the 10MFP as soon as the set limits are breached. The ten test results below show the effect of having the hysteresis on or off:

	Hysteresis feature ON 10MFP Trolley status		Hysteresis feature OFF 10MFP Trolley status	
Test 1 result – 20/16/13	OFF		OFF	
Test 2 result – 21/16/13		ON		ON
Test 3 result – 20/16/13		ON	OFF	
Test 4 result – 18/17/14		ON		ON
Test 5 result – 18/16/13		ON	OFF	
Test 6 result – 17/16/11		ON		ON
Test 7 result – 17/16/11	OFF		OFF	
Test 8 result – 18/17/13	OFF		OFF	
Test 9 result – 19/17/14		ON		ON
Test 10 result – 19/17/13		ON	OFF	

ON = Relay activated, OFF = Relay not activated

NOTE: Electrical connection to a 10MFP Filtration Trolley requires the use of a relay

EXAMPLE NAS SCENARIO

An icountPDZ2 has been connected to a hydraulic system on a wind turbine. The icountPDZ2 limit relay is switched off (Normally Closed), the limits set to NAS 9 and the relay cable is connected to a Parker Guardian Filtration Unit. The icountPDZ2 activates the Guardian Filtration Unit as soon as the set limit is breached. The ten test results below show the effect of having the hysteresis on or off:

	Hysteresis feature ON Guardian Unit status		Hysteresis feature OFF Guardian Unit status	
Test 1 result = 9	OFF		OFF	
Test 2 result = 9	OFF		OFF	
Test 3 result = 10		ON		ON
Test 4 result = 9		ON	OFF	
Test 5 result = 10		ON		ON
Test 6 result = 8	OFF		OFF	
Test 7 result = 7	OFF		OFF	
Test 8 result = 10		ON		ON
Test 9 result = 9		ON	OFF	
Test 10 result = 10		ON		ON

ON = Relay activated, OFF = Relay not activated


NOTE: Electrical connection to a Guardian Filtration unit requires the use of a relay

Interpreting data

Solid contaminants in fluid power systems vary in size, shape, form and quantity. The most harmful contaminants are normally between 6 microns and 14 microns. The ISO code is the preferred method of reporting quantity of contaminants.

The ISO code number corresponds to contamination levels pertaining to three sizes.

The first scale number represents the number of particles larger than 4 $\mu\text{m(c)}$ per 100 millilitre of fluid, the second number for particles larger than 6 $\mu\text{m(c)}$ per 100 millilitre of fluid and the third number for particles larger than 14 $\mu\text{m(c)}$ per 100 millilitre of fluid.



Note that interpolation (i.e. estimation within the measured range) is acceptable; extrapolation (i.e. estimation outside of the measured range) is not.

ISO contamination numbers

Range number	Number of particles per 100ml	
	More than	Up to and including
24	8×10^6	16×10^6
23	4×10^6	8×10^6
22	2×10^6	4×10^6
21	1×10^6	2×10^6
20	500×10^3	1×10^6
19	250×10^3	500×10^3
18	130×10^3	250×10^3
17	64×10^3	130×10^3
16	32×10^3	64×10^3
15	16×10^3	32×10^3
14	8×10^3	16×10^3
13	4×10^3	8×10^3
12	2×10^3	4×10^3
11	1×10^3	2×10^3
10	500	1×10^3
9	250	500
8	130	250
7	64	130
6	32	64
5	16	32
4	8	16
3	4	8
2	2	4
1	1	2

For example: code 20/18/13 indicates that there are between 500,000 and 1,000,000 particles larger than 2 microns, and between 130,000 and 250,000 particles larger than 5 microns, and between 4000 and 8000 particles larger than 15 microns.


REFERENCE ISO 4406:1999

When the raw data in one of the size ranges results in a particle count of fewer than 20 particles, the scale number for that size range is labelled with the symbol '>'.

For example, a code of **14/12/>7** signifies that there are more than 8,000 and up to and including 16,000 particles equal to or larger than $4\mu\text{m}$ (c) per 100 ml and more than 2,000 and up to and including 4,000 particles equal to or larger than $6\mu\text{m}$ (c) per 100 ml. The third part of the code, >7 indicates that there are more than 64 and up to and including 130 particles equal to or larger than $14\mu\text{m}$ (c) per 100 ml. But the $14\mu\text{m}$ (c) part of the code could actually be 7, indicating a particle count more than 130 particles per 100 ml.

ISO4406 particle distribution chart

The chart includes various ISO level contamination grades



NAS 1638 chart

	Size range μm	5–15	15–25	25–50	50–100	>100
Classes (based on maximum contamination limits, particles per 100ml)	00	125	22	4	1	0
	0	250	44	8	2	0
	1	500	89	16	3	1
	2	1000	178	32	6	1
	3	2000	356	63	11	2
	4	4000	712	126	22	4
	5	8000	1425	253	45	8
	6	16,000	2850	506	90	16
	7	32,000	5700	1012	180	32
	8	64,000	11,400	2025	360	64
	9	128,000	22,800	4050	720	128
	10	256,000	45,600	8100	1440	256
	11	512,000	91,000	16,200	2880	512
	12	1,024,000	182,400	32,400	5760	1024

ISO/NAS/SAE comparison chart

BS 5540/4	Defence Std. 05/42		NAS 1638	SAE 749
	Table A	Table B		
11/8			2	
12/9			3	0
13/10			4	1
14/9		400F		
14/11			5	2
15/9	400			
15/10		800F		
15/12			6	3
16/10	800			
16/11		1300F		
16/13			7	4
17/11	1300	2000		
17/14			8	5
18/12	2000			
18/13		4400F		
18/15			9	6
19/13	4400	6300F		
19/16			10	
20/13	6300			
20/17			11	
21/14	15,000			
21/18			12	
22/15	21,000			
23/17	100,000			

The above comparisons relate to particle count data only. To confirm to any particular standard, reference should be made to the recommended experimental procedure.

Component cleanliness guidelines

Suggested acceptable contamination levels for various hydraulic systems.



Target contamination class to ISO 4406		Suggested maximum particle level		Sensitivity	Type of system	Typical components
6µm	14µm	6µm	14µm			
13	9	4000	250	Super critical	Silt-sensitive control system with very high reliability. Laboratory or aerospace.	High performance servovalves
15	11	16,000	1,000	Critical	High performance servo and high pressure long life systems, e.g. aircraft, machine tools etc.	Industrial servovalves
16	13	32,000	4,000	Very important	High quality reliable systems. General machine requirements.	Piston pumps, proportional valves, compensated flow controls
18	14	130,000	8,000	Important	General machinery and mobile systems. Medium pressure, medium capacity.	Vane pumps, spool valves
19	15	250,000	16,000	Average	Low pressure heavy industrial systems, or applications where long life is not critical.	Gear pumps, manual and poppet valves, cylinders
21	17	1,000,000	64,000	Main protection	Low pressure systems with large clearances.	Ram pumps

Viscosity charts

The following charts indicate the differential pressure required to run a successful test at the appropriate flow rates.

Example: If the fluid you wish to analyse has a relative viscosity to 60 cSt, to generate the optimum flow rate 60ml/min a differential pressure of 0.5bar is required.

If the fluid you wish to analyse has a relative viscosity of 400 cSt, a 4 bar differential pressure would result in 130 ml/min.



ISO contamination charts


Typical system applications and code numbers

These typical applications and ISO code numbers are taken from the UK Contamination and Control Research Programme (1980–1984).

Ref. AHM Guide to Contamination Control in Hydraulic Power Systems – 1985


SOLID CONTAMINANT CODE NO 13/10

Application: Aircraft test stands




SOLID CONTAMINANT CODE NO 18/11

Application: Mobile systems




SOLID CONTAMINANT CODE NO 17/12

Application: Marine installations




SOLID CONTAMINANT CODE NO 18/13

Applications: Mechanical handling



**SOLID CONTAMINANT CODE NO
16/11**

Applications: Injection moulding;
Metalworking;
Unused commercial-grade oil



Ordering Information

STANDARD PRODUCTS TABLE

Part Number	Fluid type	Calibration	Display	Limit Relay	Communications	Moisture sensor	Cable connector kit
IPDZ12122230	Mineral	MTD	None	Yes	RS232 / 4–20mA	Yes	M12, 8-pin plug connector
IPDZ12121230	Mineral	MTD	None	Yes	RS232	Yes	M12, 8-pin plug connector
IPDZ12123230	Mineral	MTD	None	Yes	RS232 / 0–5V	Yes	M12, 8-pin plug connector
IPDZ12125230	Mineral	MTD	None	Yes	RS232 / CAN-bus	Yes	M12, 8-pin plug connector

PRODUCT CONFIGURATOR

Key	Fluid type		Calibration		Display		Limit Relay		Comms		Moisture sensor		Cable connector kit	
IPD	1	Mineral	1	ACFTD	1	None	1	No	1	RS232	1	No	00	No
IPDZ	2	Phosphate ester	2	MTD	2	LED	2	Yes	2	RS232 / 4–20mA	2	Yes	10	Deutsch 12-pin DT series connector
IPDR	3	Aviation fuel (4 channels)	3	AS4059	3	Digital			3	RS232 / 0–5V			30	M12, 8-pin plug connector
					4	GSM			4	RS232 / RS485				
									5	RS232 / CAN-bus				

IPDZ2 OPTIONS NOT CONFIGURABLE

Key	Fluid type		Calibration		Display		Limit Relay		Comms		Moisture sensor		Cable connector kit	
IPDZ					2	LED			4	RS232 / RS485			00	No
					3	Digital							10	Deutsch 12-pin DT series connector
					4	GSM								

ACCESSORY PART NUMBERS

Description	Part number
Single Point Sampler	SPS2021
External flow device	S840074
Power supply	ACC6NN013
2 x 10 metre M12, 8-pin plug and socket Ultra Lock cable kit	ACC6NN021
RS232 to USB converter	ACC6NN017

SENSOR PART NUMBERS

Product number	Supersedes	Size	Flow range (l/min)	Fluid type	Port thread (inches)
STI0144100	STI.0144.100	0	6–25	Mineral fluid	3/8
STI1144100	STI.1144.100	1	20–100	Mineral fluid	3/4
STI2144100	STI.2144.100	2	80–380	Mineral fluid	1 1/4

Parker Worldwide

AE – UAE, Dubai
Tel: +971 4 8875600
parker.me@parker.com

AR – Argentina, Buenos Aires
Tel: +54 3327 44 4129

AT – Austria, Wiener Neustadt
Tel: +43 (0)2622 23501-0
parker.austria@parker.com

AT – Eastern Europe, Wiener Neustadt
Tel: +43 (0)2622 23501 970
parker.easteurope@parker.com

AU – Australia, Castle Hill
Tel: +61 (0)2-9634 7777

AZ – Azerbaijan, Baku
Tel: +994 50 2233 458
parker.azerbaijan@parker.com

BE/LU – Belgium, Nivelles
Tel: +32 (0)67 280 900
parker.belgium@parker.com

BR – Brazil, Cachoeirinha RS
Tel: +55 51 3470 9144

BY – Belarus, Minsk
Tel: +375 17 209 9399
parker.belarus@parker.com

CA – Canada, Milton, Ontario
Tel: +1 905 693 3000

CH – Switzerland, Etoy
Tel: +41 (0) 21 821 02 30
parker.switzerland@parker.com

CN – China, Shanghai
Tel: +86 21 5031 2525

CZ – Czech Republic, Klecany
Tel: +420 284 083 111
parker.czechrepublic@parker.com

DE – Germany, Kaarst
Tel: +49 (0)2131 4016 0
parker.germany@parker.com

DK – Denmark, Ballerup
Tel: +45 43 56 04 00
parker.denmark@parker.com

ES – Spain, Madrid
Tel: +34 902 33 00 01
parker.spain@parker.com

FI – Finland, Vantaa
Tel: +358 (0)20 753 2500
parker.finland@parker.com

FR – France, Contamine s/Arve
Tel: +33 (0)4 50 25 80 25
parker.france@parker.com

GR – Greece, Athens
Tel: +30 210 933 6450
parker.greece@parker.com

HK – Hong Kong
Tel: +852 2428 8008

HU – Hungary, Budapest
Tel: +36 1 220 4155
parker.hungary@parker.com

IE – Ireland, Dublin
Tel: +353 (0)1 466 6370
parker.ireland@parker.com

IN – India, Mumbai
Tel: +91 22 6513 7081-85

IT – Italy, Corsico (MI)
Tel: +39 02 45 19 21
parker.italy@parker.com

JP – Japan, Fujisawa
Tel: +(81) 4 6635 3050

KR – South Korea, Seoul
Tel: +82 2 559 0400

KZ – Kazakhstan, Almaty
Tel: +7 7272 505 800
parker.easteurope@parker.com

LV – Latvia, Riga
Tel: +371 6 745 2601
parker.latvia@parker.com

MX – Mexico, Apodaca
Tel: +52 81 8156 6000

MY – Malaysia, Subang Jaya
Tel: +60 3 5638 1476

NL – The Netherlands, Oldenzaal
Tel: +31 (0)541 585 000
parker.nl@parker.com

NO – Norway, Ski
Tel: +47 64 91 10 00
parker.norway@parker.com

NZ – New Zealand, Mt Wellington
Tel: +64 9 574 1744

PL – Poland, Warsaw
Tel: +48 (0)22 573 24 00
parker.poland@parker.com

PT – Portugal, Leca da Palmeira
Tel: +351 22 999 7360
parker.portugal@parker.com

RO – Romania, Bucharest
Tel: +40 21 252 1382
parker.romania@parker.com

RU – Russia, Moscow
Tel: +7 495 645-2156
parker.russia@parker.com

SE – Sweden, Spånga
Tel: +46 (0)8 59 79 50 00
parker.sweden@parker.com

SG – Singapore
Tel: +65 6887 6300

SK – Slovakia, Banská Bystrica
Tel: +421 484 162 252
parker.slovakia@parker.com

SL – Slovenia, Novo Mesto
Tel: +386 7 337 6650
parker.slovenia@parker.com

TH – Thailand, Bangkok
Tel: +662 717 8140

TR – Turkey, Istanbul
Tel: +90 216 4997081
parker.turkey@parker.com

TW – Taiwan, Taipei
Tel: +886 2 2298 8987

UA – Ukraine, Kiev
Tel: +380 44 494 2731
parker.ukraine@parker.com

UK – United Kingdom, Warwick
Tel: +44 (0)1926 317 878
parker.uk@parker.com

US – USA, Cleveland
Tel: +1 216 896 3000

VE – Venezuela, Caracas
Tel: +58 212 238 5422

ZA – South Africa, Kempton Park
Tel: +27 (0)11 961 0700
parker.southafrica@parker.com

www.parkerhfde.com

European Product Information Centre
(24-hour)

Freephone: +00800 27 27 5374

(from AT, BE, CH, CZ, DE, EE, ES, FI,
FR, IE, IT, PT, SE, SK, UK)

© 2010 Parker Hannifin Corporation.
All rights reserved.

B.84.833_IPDZ2M_GB_Ver A

